FT SERIES

Hydrogenation Unit – FT67

The Armfield Hydrogenation unit is a floor-standing batch processing vessel, which is used to adjust the degree of saturation of 25 litre batches of edible oils.

Increasing the saturation improves the stability and lengthens the shelf-life of the product.



Features / benefits

- ▶ Only 25 litres of oil to be hydrogenated
- ► Safe and easy to use
- ► Reusable filter mesh
- ► Stainless steel pressure vessel
- ► Liquid ring vacuum pump
- Extraction pump
- ► Pressure leaf filter
- ► Air driven agitators
- ► Integral steam heating coil and cooling coil
- ► Temperatures to 180°C
- ► Safe zoned controls
- ► Accurate control of hydrogen addition
- ► Window for safe viewing

UK office - email: sales@armfield.co.uk tel: +44 (0) 1425 478781 (for ROW) USA office - email: info@armfield.inc tel: +1 (609) 208-2800 (USA only)

Issue: 2

URL: http://www.armfield.co.uk/ft67

e reserve the right to amend these specifications without prior notice. E&OE © 2019 Armfield Ltd. All Rights Reserved

Description

The main processing vessel is situated in a floor-standing stainless steel framework, which also houses a catalyst mixing tank, filter pump, pressure leaf filter and vacuum pump. All equipment in contact with the process fluid is manufactured from stainless steel.

The hydrogenation vessel has a batch capacity of 25 litres.

It is a vertical cylindrical vessel, which incorporates a cooling/steam heating coil, hydrogen gas sparge ring, variable speed turbine agitator and baffle arrangement.

The hydrogen addition cycle results in an exothermic reaction and maintenance of the operating temperature is achieved by circulating metered cooling water through the submerged cooling coil, which removes the excess heat from the reaction.

Initial heating to the reaction temperature is by steam, also in the immersed coil. A steam pressure control station enables pressures of up to 10.0 bar on the coil so that process temperatures of up to 180°C can be achieved.

The turbine agitator is driven by a pneumatic motor through a mechanical seal in the lid of the vessel. Rotational speed is varied by adjusting the pressure of the compressed air driving the motor. A maximum speed of 2500 rpm* can be achieved. The propeller mixer in the catalyst preparation tank is also driven by pneumatic motor and is capable of rotating at speeds up to 850 rpm*. Pneumatics are used as the motive force as the presence of hydrogen gas requires minimal use of electrical components. Only the filter charge pump and the liquid ring vacuum pump are driven by electric motor.

The centrifugal filter charge pump enables efficient filtering of the catalyst from the oil by the pressure leaf filter, which is a reusable filter requiring no replacement of the filter element. If necessary, filter aid in the form of a diatomaceous earth can be mixed in the catalyst tank and added to the oil charge prior to filtering.

The process vessel and filter are designed fully in accordance with the BS 5500 code for pressure vessels. Vacuum levels of 65 mbar are achieved in the reactor vessel by the liquid ring vacuum pump. Reduced system pressures are necessary to prevent oxidation during the heating cycle and assist in the removal of any water present in the oil. Also, the suction pressure is used to charge the vessel with oil and for the addition of catalyst and filter aid.

* - no load condition.

Modes of operation

Heating, Hydrogeneration/Agitation, Cooling.

In order to increase the degree of saturation of edible oils to adjust their physical characteristics, the oil must be mixed with hydrogen gas in the presence of a catalyst under very precisely controlled process conditions. On completion of the reaction, the catalyst must be completely removed by an efficient filtration operation.

The Hydrogenation unit achieves this by use of a variable speed turbine impeller and baffle arrangement, which enables efficient gas/liquid mixing, and accurate control of the pertinent process parameters.

Oil is heated to the desired reaction temperature then hydrogen gas is admitted and fills the vapour space to the pressure required. The progress of the reaction is monitored by regular sample taking and the process stopped when the desired degree of saturation has been obtained


The Filtration Process

A pressure leaf type filter is used to filter out the catalyst. Due to the small quantities of catalyst involved, a diatomaceous earth is often added to the oil as a filter aid.


This type of filter is the standard used in industry for this duty and provides a convenient method for familiarisation with the operating sequence of such a filter.

Performance

As a guideline to the performance of the hydrogenation unit, typically, using 0.05 - 0.1% active nickel and pure hydrogen, the iodine value (degree of saturation) of cottonseed oil will reduce from 108 to 70 in 40-60 minutes.







Above: The graph indicates the increase in saturation of sunflower oil with time. It was produced from tests carried out by The University of Leeds -Department of Food Science.



Technical specifications

All electrical equipment used on the unit is scheduled flameproof suitable for use in a zone 1 area, which is an area in which an explosive gas air mixture is likely to occur in normal operation. Due to the use of hydrogen gas, the Hydrogenation Unit must be installed in an area designated as safe.

Relevant local regulations regarding the operation of this type of equipment must be adhered to.

Hydrogenation vessel	
Total volume	25 litres
Cooling/heating coil surface area	0.08m ²
Maximum working temperature	180°C
Normal working pressure	0.7bar and 65mbar
Maximum working pressure	2bar
Agitator drive	pneumatic motor/gearbox
Maximum speed	2500rpm
Catalyst tank	
Volume	4.0 litres
Stirrer	pneumatic drive, to 850rpm
Filter pump	
Туре	centrifugal
Impeller	closed
Capacity	100 l/m @ 2.75 bar
Liquid ring vacuum pump	
Capacity	66.0m³/hr
Sealant	water
Sealant flow rate	6.0 l/m
Normal operating pressure	65mbar
Pressure leaf filter	
Material	stainless steel
Filter volume	3.8 litres
Filter cake capacity	1.0 litre
Filtering area	0.09m ²
Filter screen	110 mesh (0.3mm wire)
Maximum pressure	3.0 bar

Overall dimensions	
Length	1.25m
Width	0.95m
Height	1.85m
Packed and crated shipping specifications	
Volume	2.5m³
Gross weight	500Kg

Requirements

Scale





Electricity supply: Three phase (see ordering codes)Steam supply: 10 kg/hr @ 10 bar min. pressure

Compressed air: 25 l/s @ 6 bar min - 10 bar max pressure
Cooling Water: 20 l/m @ 3 bar min - 5 bar max pressure
Compressed Gas: Hydrogen - 20 l/m @ 2 bar max pressure

Requires an ATEX approved safe working area



Ordering codes

► FT67-C: 415V/3ph/50Hz, (6.5kW)
► FT67-D: 208V/3ph/60Hz, (8.5kW)
► FT67-E: 380V/3ph/50Hz, (6,5kW)
► FT67-F: 220V/3ph/60Hz, (8.5kW)

Knowledge base

> 28 years expertise in research & development technology

laboratory needs, latest project or application.

> 50 years providing engaging engineering teaching equipment Benefit from our experience, just call or email to discuss your

Products (€ certified armfield.co.uk

An ISO 9001:2015 Company



Installation Commissioning Training Service and maintenance Support: armfieldassist.com